
# innovaphone IP200 / IP230 / IP240



# EN Short user guide innovaphone IP200 / IP230 / IP240

	EN
	lcons
Ъ	Speaker on
Cŧ	Microphone on (hands-free)
<b>L</b>	Call diversion activated
0-	Phone locked, can only be unlocked with PIN
	Handset active (handset off-hook)
	Headset on
	Encrypted telephone connection
<b>~</b>	Registration successful
$\triangleleft$	Registration failed

Key	In idle state	During call
Menu key	Opens the menu and leaves the menu confir- ming changes made	Sets up conference with two active calls
Ok key <b>Ok</b>	Confirms the current selection or entry	
Enter	Confirms the current selection or entry	
R key	Displays in-bound call list	Sets up a consultation call, switches between two calls
Redial	Displays out-bound call list	Forwards the incoming call or active call
Speaker	Prepares call, picking up a call in hands-free mode	Listen-in, switch to hands-free mode
Microphone	Silences telephone, switches ringing tone off	Mute / mute key swit- ches microphone off
Disconnect	Exit menu, return to home screen	Terminates call
Delete (IP240)	Deletes the character to the right of the cursor	
Delete Del	Deletes last character in editor mode	
Backspace	Deletes last character in editor mode	
Escape Esc	One level back in menu without saving settings	Terminates call
Stop	One level back in menu without saving settings	Terminates call

Stop

## Display components (see numbering on illustrations)

- 1 Name of active registration 2
- Own extension number
- 3 Contact field
- 4 Display icons 1
- 5 Date and time
- 6 Display icons 2
- 7 Current connection time

## Actions for incoming calls

Accept call: Pick up handset, press d to pick up call in hands-free mode

### Reject call: Press

Call diversion: Press () before accepting the call, enter telephone number for the call diversion and confirm by pressing () again.

#### Actions in idle state

Dialling: Enter telephone number; to dial by name, long press to change to characters and enter name, use arrow keys to select desired name if necessary, pick up handset to initiate call.

Call completion on missed call: Press **R**, if necessary press arrow keys to select desired call, pick up handset to initiate call.

Re-dial: Press O , select entry with arrow keys if necessary and pick up handset to initiate call.

Send message: Enter telephone number or name, press ->>> , select send message and enter the desired text, send by pressing  $\rightarrow$ .

Set call diversion: Press ->, select user setup, select call diversion by entering the target number under the required condition. Press twice to save the setting.

Set presence: Press 3, select user setup and presence. Set required activity and add note as necessary.

## Actions during call

Change to hands-free: Keep d pressed and hang up.

Terminate hands-free: Pick up handset or terminate call by pressing ....

Consultation: Press R. select number or name for consultation call. Terminate consultation with **error** and return to initial call.

Switch between calls: Press R and set up second call. Double press R to switch between calls. Press  $\bullet \bullet \bullet$  to terminate calls.

Transfer: Press R and set up second call. Hang up to connect the two calls to each other

*Conference:* Set up two calls using the  $\mathbf{R}$  key and switch to conference with  $\rightarrow$ . Press  $\rightarrow$  again to separate calls or hang up to terminate.

*Quick transfer:* Press **R** and dial target number required. If you hang up before the call is initiated, the caller will hear the ring- tone until the person being called picks up the call.

Blind transfer: Press () and set up second call. Press () once more to connect calls together without the callers being put in the wait queue.

#### Actions when initiating a call

Call completion on busy subscriber: Initiate call, press  $\rightarrow$  when you hear busy tone or call waiting signal, then select recall. The telephone will indicate when the subscriber is available again.

*Call completion on no reply:* Initiate call, press  $\rightarrow$  while hearing the ring tone, and select recall. The telephone will indicate when the subscriber is active again.

to change